Tenda®

W322U Quick Installation Guide

www.tenda.cn

1 Package Contents

W322U
11N Wireless USB Adapter

CD-ROM

Quick Installation Guide

2 Insert the Wireless USB Adapter into the USB port of your computer.

Or

3 "Found New Hardware" system dialogue appears, and select"cancel".

4 Insert the included CD-ROM into the CD-ROM drive.

Note:

If this window doesn't appear automatically, please open the Setup Wizard on CD-ROM and double click the "Setup"icon.

5 Click "Start"to display the following page.

6 Click "Next".

7 Click "Next" to start installing the driver and utility interface.

8 During the installation, the following dialogue maybe appears. Click "Continue Anyway"in XP or "Install this driver software anyway"in Vista to continue installation. There is no security threat to your computer.



(XP)

OR

Windows can't verify the publisher of this driver software
Don't install this driver software
Install this driver software anyway

(Vista)

W322U Quick Installation Guide
www.tenda.cn

9 Click "Finish" to complete the installation.

10 After the installation, the utility interface will run automatically.

11 In "Site Survey", click the wireless network you needed, click "Connect" and "OK" to connect with the selected wireless network.

12 In Status page, if the Status shows connected and IP address has been obtained, it means the device has been connected with wireless network successfully.

Notice:

Tenda recommends you to use the included utility interface for settings. Also you can configure the device via the Windows wireless setting program.

Application Plan:

TENDA is the registered trademark of Shenzhen Tenda Technology Co., Ltd. All the products and product names mentioned herein are the trademarks or registered trademarks of their respective owners © 2007 TENDA All Rights Reserved.

Manufacturer: SHENZHEN TENDA TECHNOLOGY CO., LTD.
Address: 3F, Mose Industrial Building, No. 1031, Liming Road, Xili Town, Nanshan District, Shenzhen P.R. CHINA 518055
Technical Support: support@tenda.com.cn
Telephone: 0086 755 2765 7180
Email: sales@tenda.com.cn
Website: http://www.tenda.cn